

OPERATION AND MAINTENANCE GUIDE: YOUR HRV + FURNACE SYSTEMS

Not only do dirty filters affect the air quality of your home, but they also put extra strain on both your furnace and HRV units. This could significantly increase your energy bills.

Follow these maintenance routines to keep your furnace and HRV in good shape, and to improve the overall health of your home.



Take note:



Your HRV system should stay running 24 hours a day, 7 days a week. The only time to shut off your unit is when you are running your air conditioner.



Remember, once your A/C unit has been shut down, the HRV system should be turned back on.



A humidity level between 35-40% is normal depending on the finishes chosen in your home.



Check the humidity levels in your home seasonally.



If your home is too dry, consider purchasing a small humidifier to run with your furnace.



If moisture levels are too high, you may also consider purchasing a small dehumidifier to run with your furnace.

